

RK ROYAL KLUDGE


USER MANUAL

Mechanical Keyboard


English
Русский

166-88801-05

PRODUCT BASIC English



Keyboard




TYPE-C-C-A Cable




User Manual

WIRED MODE English




TYPE-C-C-A Cable

BACKLIGHT CONTROL English



- | | |
|---|--|
| Fn + Back ☑ Switch Backlight Mode | Fn + Fn (The same applies to RGB) Monochrome switching |
| Fn + ↑ * Backlight Brightness + | Fn + ↻ Backlight Speed + |
| Fn + ↓ * Backlight Brightness - | Fn + ↻ Backlight Speed - |
| Fn + Win 🗄 Windows Lock | Fn + ↶ Restore to factory settings |
| Fn + ↵ Side light adjustment | Fn + Off Turn off/on all lights |

CUSTOM BACKLIGHT SET English




MULTIMEDIA KEY FOR WINDOWS English

- Windows mode (Fn + A: switch to Windows system)
- | | |
|----------------------------------|------------------------------------|
| Fn + F1 Computer | Fn + F7 Last song |
| Fn + F2 Browser | Fn + F8 Play / pause |
| Fn + F3 Mailbox | Fn + F9 Next song |
| Fn + F4 Calculator | Fn + F10 Mute |
| Fn + F5 Player | Fn + F11 Volume- |
| Fn + F6 Stop | Fn + F12 Volume+ |

MULTIMEDIA KEY FOR MAC English

- MAC mode (Fn + s: switch to MAC system)
- | | |
|--|------------------------------------|
| Fn + F1 Screen Brightness- | Fn + F8 Play / pause |
| Fn + F2 Screen Brightness+ | Fn + F9 Next song |
| Fn + F5 Keyboard Backlight Brightness- | Fn + F10 Mute |
| Fn + F6 Keyboard Backlight Brightness+ | Fn + F11 Volume- |
| Fn + F7 Last song | Fn + F12 Volume+ |


INDICATOR LIGHT PROMPT FUNCTION (FROM LEFT TO RIGHT) English




- 1.Caps Lock
- 2.Scrik
- 3.WIN Lock
- 4.MAC: MAC system is always on

Download Driver Address: www.rkgaming.com/download/1/

КОМПЛЕКТАЦИЯ Русский



Клавиатура




Кабель TYPE-C-C-A




Руководство пользователя

ПРОВОДНОЙ РЕЖИМ Русский



Кабель TYPE-C-C-A

УПРАВЛЕНИЕ ПОДСВЕТКОЙ Русский



- | | |
|---|--|
| Fn + Back ☑ Сменить режим подсветки | Fn + Fn ⚙ Смена цвета |
| Fn + ↑ * Яркость + | Fn + ↻ Скорость подсветки + |
| Fn + ↓ * Яркость - | Fn + ↻ Скорость подсветки - |
| Fn + Win 🗄 Windows Lock | Fn + ↶ Сброс до заводских настроек |
| Fn + ↵ Настройка бокового света | Fn + Off Выключить всю подсветку |

ПЕРСОНАЛИЗАЦИЯ ПОДСВЕТКИ Русский



МУЛЬТИМЕДИЙНЫЕ КЛАВИШИ ДЛЯ WINDOWS Русский

- Режим Windows (Fn+A: переключить на Windows)
- | | |
|-----------------------------------|--|
| Fn + F1 Компьютер | Fn + F7 Предыдущая песня |
| Fn + F2 Браузер | Fn + F8 Играть / пауза |
| Fn + F3 Почта | Fn + F9 Следующая песня |
| Fn + F4 Калькулятор | Fn + F10 Выключить звук |
| Fn + F5 Плеер | Fn + F11 Громкость - |
| Fn + F6 Стоп | Fn + F12 Громкость + |

МУЛЬТИМЕДИЙНЫЕ КЛАВИШИ ДЛЯ MAC Русский

- Режим MAC (Fn+S: переключить на MAC)
- | | |
|---|---------------------------------------|
| Fn + F1 Яркость - | Fn + F8 Играть / пауза |
| Fn + F2 Яркость + | Fn + F9 Следующая песня |
| Fn + F5 Яркость подсветки - | Fn + F10 Выключить звук |
| Fn + F6 Яркость подсветки + | Fn + F11 Громкость - |
| Fn + F7 Предыдущая песня | Fn + F12 Громкость + |

СВЕТОВЫЕ ПОДСКАЗКИ (СЛЕВА НАПРАВО) Русский



- 1.Caps Lock
- 2.Scrik
- 3.WIN Lock
- 4.Mac: Система MAC всегда включена.

Ссылка для скачивания драйверов:www.rkgaming.com/download/1/

Have an issue with one of our RK products?

Feel free to contact us with any product issues or questions. We will reply as quickly as possible to ensure all your needs are handled. Please contact the seller

⚠ WARNING: This product can expose you to chemicals including (name of one or more chemicals), which is (are) known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65warnings.ca.gov.

Executive standard:GB/T 14081-2010
Made in China www.rkgaming.com